

1. Spread the arm 1s evenly ,make sure each arm is aligned with the center rod.
2. Turn the nipple 2 into the coupler 2.
3. Turn the nipple 1 into the coupler 1.
4. Attach the cap 1 on the nipple 1 .
5. Attach the cover 1,tube and cover 2 on the nipple 1 then secure by the loop.
6. Use the nipple 3 to attach the arm 1 and arm 2 then secure by the ball as the drawing shows.
7. Turn the finial onto the nipple 4.
8. Put the cup on the tube .

