

⚠ WARNING

RISK OF ELECTRIC SHOCK

- Do not use in wet locations.
- Use indoors only.
- Turn power off before servicing - see instructions.
- Properly ground fixture.
- Ensure that no bare wires are exposed outside the electrical connections.

BULB MAY SHATTER AND CAUSE INJURY IF BROKEN



- Do not use excessive force when installing bulb.

RISK OF BURN

- Allow bulb to cool before handling.

INSTALLATION PROCEDURES

1. Turn off power.
Note: All installations should comply with local electrical codes. If you have any doubts concerning installation contact a qualified licensed electrician.
2. On one side of wire module there are two gates. Feed approximately 5 inches of Type NM non-metal sheathed cable (12 gauges maximum) through gate.
Note: These gates serve as strain relieves holding cable securely in place. Gates should not be removed and no more than one cable should go through each.
3. Peel back jacket on cable to within one inch of inside of gate
4. Strip approximately 1/2 inch of insulation each black and white wire.



5. Push stripped wires into the appropriate connector:

- black to black
- white to white
- green to green

6. Slightly tug on each wire to insure connection has been made and is secure.

7. Push wire module to mounting surface of cabinet (as close to wall as possible) allowing excess cable to feed back into wall. Secure wire module in place using provided screws. It may be necessary to drill 1/16" maximum pilot holes.

8. Push wires and connectors inside wire module. We suggest pushing each connector towards a different corner of wire module.

9. Strip legs on wire module cover into slots inside wire module and until cover snaps in place.


10. Note: To remove cover, slide screwdriver into slot formed by cover and wire module then pull screwdriver handle away from wire module until cover separates from wire module.



MODEL

87849WT	87859WT
87851WT	87861WT
87852WT	87862WT
87853WT	87863WT
87849MB	87859MB
87851MB	87861MB
87852MB	87862MB
87853MB	87863MB

9. Determine desired location for mounting fixture. Mounting surface should be a minimum of 1/2" thick and approximately 2 1/2" clearance for interconnect cable should be allowed at both ends of fixture.
10. Position fixture against mounting surface with bulb compartment towards back.



11. Drive pre-installed screws into mounting surface until fixture is secure. If screws are difficult to install, remove screws and bushings, mark holes, and drill 1/16" maximum pilot holes.
12. Connect fixture to wire module using interconnect cable.


13. Hold interconnect cable to mounting surface and determine best path for cable.
Note: Interconnect cable is not intended for use through or concealed behind walls, floors or ceilings.

14. Peel backing off retaining clips(s) and affix to desired location(s). Surface should be as clean as possible.

15. Slip cable into clip(s) and snap closed.

16. If no other fixtures will be added at this time use connector cover over connectors not being used.

17. Maximum number of lamps per run cannot exceed 25 lamps.



OPENING DIFFUSER:

1. Turn off fixture and allow to cool.
2. Place finger tip on tab of each diffuser end cap.
3. Slide top and diffuser forward.
4. Lower that edge of diffuser.

CLOSING DIFFUSER:

- A. Swing edge of diffuser with tabs up toward fixture until pegs by tabs slip into slot at the end of fixture end caps.
- B. Slide top and diffuser towards rear of fixture to lock.



BULB REPLACEMENT INSTRUCTIONS

Re-lamp only with Max. 18 Watt, 12 Volt, TYPE T-5 wedge base incand bulb.

1. Turn the light off and allow time for bulb (lamp) to cool before handling.
2. Open the glass cover with your finger tips (See illustration). Be careful not to drop the glass lens which can break!
3. Using a cloth or towel grasp the bulb firmly and pull bulb out of socket. Insert new bulb using a paper towel or cloth to hold the bulb.
4. Position the glass lens by sliding tabs forward allowing pegs to seat in slots.

Note:
For 87859WT/MB 87861WT/MB 87862WT/MB 87863WT/MB you can connect with other fixture with the link cord(not provided).

